

PGA VoIP

4G MOBILE NETWORK GATEWAY EQUIPMENT FOR ELEVATORS



SUMMARY

GENERAL WARNINGS	<u>5</u>
General Remarks	<u>5</u>
DESCRIPTION	<u>6</u>
Main Features	<u>8</u>
LEDS	<u>8</u>
INSTALLATION	<u>10</u>
Installation Advice	<u>10</u>
Mounting	<u>11</u>
SIM Card Insertion	<u>12</u>
Antenna Installation	<u>13</u>
Emergency Alarm System	<u>14</u>
Power Supply Connection	<u>15</u>
Battery	<u>16</u>
SWITCH ON	<u>16</u>
PROGRAMMING BY HANDSET	<u>17</u>
SMS PROGRAMMING	<u>18</u>
PROGRAMMING VIA MQTT OVER IP	<u>19</u>
Operating Mode	<u>20</u>
Roaming Configuration	<u>20</u>
Transmission/Reception Gain Adjustment	<u>20</u>
Battery Status Reading	<u>20</u>
Handset Number for Administration	<u>21</u>
Password Programming	<u>21</u>
Dialed Phone Number Converter	<u>21</u>
Network Signal Strength Measurement	<u>21</u>
Network Type Setting	<u>21</u>
Handset Number for Notification	<u>21</u>
Telephone Line Voltage	<u>22</u>
Restart (Reboot)	<u>20</u>
Factory Reset	<u>20</u>

SUMMARY

IP VOLTE PROGRAMMING	24
Selected APN	25
Translation Mode	25
Server Address	25
Server Port	25
Password	25
Username	25
Receiver Gain Reading / Adjustment	25
PROGRAMMING VIA VOIP	27
DTMF Mode in VoIP	27
VoIP Receive Volume	27
Call Mode	27
Codec	27
Transport Layer	27
Username	27
Mot de passe	27
Serveur	27
Port	27
Timout de session SIP	27
PROGRAMMING VIA WiFi	28
WiFi Hotspot Sharing Activation	28
WiFi Security Level Configuration	28
WiFi Password	28
WiFi SSID Configuration	28
ROAMING	29
GAIN SETTINGS	29
AUTO CONVERTER FOR COMPOSED EXTENSION NUMBER	30
SIGNAL LEVEL MEASUREMENT	32
BATTERY ALERT	33
EXTERNAL POWER FAILURE CONTROL	34
SIM CARD PROTECTION	35
READING ADVANCED GATEWAY SETTINGS	36
BATTERY STATUS READING	37
RESTART (REBOOT)	38
FACTORY RESET	38

SUMMARY

SERVICES	<u>39</u>
VoLTE	<u>39</u>
PROVISIONING	<u>40</u>
REMOTE IP PROGRAMMING	<u>40</u>
LED STATUS GUIDE	<u>41</u>
GREEN - 2G / 3G / 4G network strength	<u>41</u>
RED - Mobile network connection	<u>42</u>
ORANGE - <i>COMMING SOON</i>	<u>42</u>
BLUE - Power status	<u>43</u>
White - Line status	<u>43</u>
Special patterns	<u>44</u>
Manual factory reset	<u>44</u>
TROUBLESHOOTING	<u>45</u>
WARRANTY	<u>46</u>

GENERAL WARNINGS

GENERAL REMARKS

Pay close attention to the warnings in this section as they provide important information for safe installation, proper use, and proper maintenance of the product..

- The device must be used **EXCLUSIVELY** for its intended purpose, and ANEP cannot be held responsible for any damages resulting from improper use..
- Since the product has been designed in compliance with current standards, installation must take place within facilities that are compliant and meet the appropriate standards..
- Before performing any intervention inside or outside the product (cleaning, maintenance, etc.), disconnect the device from the power supply and the battery.
- For any repair intervention, please contact exclusively our after-sales service, SAVTEL..
- Install the product in a well-ventilated area, ensuring that the ventilation openings are never obstructed..
- Do not install the product in a potentially explosive environment..
- Ensure that the product is installed according to the prescribed instructions.
- Do not introduce objects, liquids, or dust, and do not use spray inside the product.
- The packaging materials should not be left within reach of children as they may pose potential hazards.
- To achieve better 4G GSM network reception, install the gateway as high as possible in the building, ideally in high machinery areas, or at the top of the elevator shaft.

RECOMMENDATIONS FOR USING NiMH BATTERIES :

The NiMH battery has a lifespan of between **500** and **1500** charge and discharge cycles, or **between 2 and 3 years**.

If the battery life drops by more than 20% (see code 62), it indicates that the battery is reaching the end of its lifespan.

- No overcharging.
- No deep discharge.
- Operating temperature between 10°C and 40°C.
- No long-term storage.

We recommend replacing the battery every 3 years.



CAUTION



Risk of explosion if the battery is replaced with an incorrect type.
Dispose of used batteries according to the instructions.





Electrical equipment must be recycled in accordance with Directive No. 2012/19/EU of 04/07/12 regarding waste electrical and electronic equipment (WEEE).

DESCRIPTION

PGA VoIP is a device that, when connected directly to a landline phone or a telealarm, allows making and receiving calls via the mobile network. A **SIM** card is required for operation.

PGA VoIP is equipped with an internal backup battery (to be connected).





MAIN FEATURES

- VoLTE Call: Operator VoIP (voice channel)
- VoLTE IP Call: Operator VoIP (voice channel)
- VoIP Call: G711 Codec, Inband/Outband RFC4733
- Wi-Fi : 2.4 GHz
- Local Programming via a telephone handset or remotely via [SMS / IP]
- Roaming Service Management
- Remote Firmware Update **(with data plan) (Minimum 5 MB)**
- Battery Charge Level Monitoring
- Notifications :
 - Power and Battery Status [SMS / IP]
 - Gateway Status every 15 minutes [IP]
- Power outage under DTMF ANEP protocol
- Fallback :
 - VoLTE Mode: Connection to the 4G network, fallback to 3G/2G (SMS and voice only)
 - IP VoLTE Mode: Fallback to VoLTE mode
 - VoIP Mode: Fallback to VoLTE mode
- Signal level reading for 4G, 3G, or 2G [LOCAL / SMS / IP]
- Automatic converter for the selected number
- Transmission and reception gain adjustment [SMS / IP]
- Wi-Fi hotspot mode
- Remote reset [LOCAL / SMS / IP]
- Mode: Inband / Outband
- Dual Band module (European 4G network)
- Direct 12V DC power input
- External transformer power input 230Vac / 12V DC
- External antenna (cable L = 2m) / (antenna with 10m cable optional)
- External adapter with socket or two-wire (input 230Vac 50 Hz, output 12V DC 1A)
- Dimensions: 142 x 125 x 41 mm
- Weight: 680g (complete package)

LEDS



Green LED : Mobile network strength in 4G, 3G, or 2G



Red LED : Mobile network connection status




Blue LED : Power status



White LED : Line status

LED STATUS GUIDE, SEE PAGE 41

> Remove the cover by pressing on the upper side.



- A Reserved space for a second antenna
- B SMA connector for the antenna cable
- C LED signal strength indicator for 2G, 3G, 4G (green)
LED mobile network connection status (red)
LED line status (white)
LED power status (blue)
- D SIM card slot (standard SIM 2FF format)
- E RJ11 connector for connecting a fixed handset or remote alarm system.
- F Terminals for connecting a fixed handset or remote alarm system.
- G External 12V power supply connection.
- H Input for external transformer power supply 230Vac / 12V DC
- I Relay contact output (maximum 125Vac or 60V DC / 1A MAX.)
- J Mini USB output

INSTALLATION

Installation Tips

- The **PGA VoIP** gateway must be installed in a location where the radio signal is sufficient for proper operation (machinery or other, or at the top of the shaft). If it is not possible to access the network with the 2m antenna, ANEP can optionally provide a 10m antenna (ref. A-EA-030) or a 5m extension cable (ref: A-EA-025).
- **The gateway must under no circumstances be installed on the cabin roof.**
- It is important to have enough space around the gateway to optimize maintenance interventions.
- The **PGA VoIP** gateway cannot be installed outdoors as it has not been designed with protection against weather elements (rain, humidity, etc.) that could damage it.
- Do not install the **PGA VoIP** gateway near other electronic devices (radio or TV equipment, computers, broadcast systems, etc.) or magnetic devices (credit cards, tickets, etc.) that may be subject to RF interference from the gateway. The recommended minimum distance is 2.5 meters.
- The **PGA VoIP** gateway should not be installed near medical devices. Its use may interfere with hearing aids or pacemakers.
- Ensure that the use of the gateway is permitted at the installation location. It should not normally be installed in hospitals, airplanes, etc.

INSTALLATION


1 MOUNTING

Check the mobile network strength using the green LED network strength indicator (see section "**LED Status Guide**", page 41).

Locate an area where the GSM signal is sufficient; ANEP recommends 3 flashes of the green LED.

Note : *The network may vary depending on the mobile operator.*

- Make two holes with a diameter of 5 mm in the wall, spaced 50 mm apart.
- Insert the two wall plugs and screw the screws until they are 5 mm from the wall.
- Insert the **PGA VoIP** device through the two rear eyelets onto the two screws on the wall.



INSTALLATION

2

SIM CARD

(STANDARD 2FF FORMAT)

Before inserting the SIM card:

- Make sure to discharge any static electricity.
- The device should be turned off to avoid damaging it.
- If resuming the contract, reset the settings to default (code 9).

Take all necessary precautions to avoid electrostatic discharges.







WARNING

If the SIM card PIN code is **ACTIVATED**, please refer to [page 35](#).
(Risk of SIM card locking)


Gently lift the front part of the SIM card slot upwards (until it is unlocked) and then lift it.

Slide the SIM card into the designated slot located on the front part

Lower the front part and push it down until it locks into place.



Chamfered edge of the chip



INSTALLATION (continued)

3 ANTENNA



WARNING


To avoid damaging the device, **NEVER** power on the PGA VoIP gateway without first installing the antenna.

Screw the antenna cable (2m) provided into the SMA connector (**B** in the photo on page 9) while fully extending the cable.


To ensure proper operation of the **PGA VoIP**, place the magnetic base antenna in a location where there are no metallic structures that could block the signal.



YES



NO



WARNING

Do not install the product near other electrical or electronic devices that were not designed to be used with it and could cause disturbances or interference.

INSTALLATION (continued)


4 TELEALARM

Connect the **PGA VoIP** device to a landline phone or a telealarm via the RJ11 connector (see **E** photo on page 9).

or

Connect the **PGA VoIP** device to a landline phone or a telealarm via the TEL terminal (see **F** photo on page 9).

Connection diagram for the ANEP BOX range





INSTALLATION (continued)

5 Power supply BY TRANSFORMER 230VAC / 12VDC

Power supply via external adapter
230Vac / 12Vdc on **terminal G**

- Connect the external adapter to the designated **G** input (see photo on page 9).

Note : It is recommended to provide appropriate electrical protection upstream of the product, in order to cut off the power supply in case of a fault.




5 OR power supply by direct 12Vdc

Power supply via direct 12Vdc / 1A
(**Terminal H**) (see photo on page 9)

- Connect the power cord to terminal **H** (see photo on page 9), ensuring correct polarity.

Note : The **maximum** supply voltage that can be provided is **12Vdc**.
The **minimum** supply voltage that can be provided is **10Vdc**.



INSTALLATION (continued)

6 BATTERY


- Connect the battery as shown here.



WARNING

The backup battery must be connected after the power supply of the **PGA VoIP**.

- Close the device cover, making sure to be careful with the power cord.



POWER ON

- Power the **PGA VoIP** gateway (see page 15).
- Wait at least 30 seconds to 3 minutes, or longer, for the gateway to be properly registered on the 4G, 3G, or 2G mobile network.
- Make sure that the mobile network connection status LED (RED) blinks rapidly once every 3 seconds, as indicated in the "**Indicators**" chapter (see page 42).

If the red mobile network connection status LED remains on (see page 42), it means the gateway is not properly connected to the 4G, 3G, or 2G network.

- Disconnect the **PGA VoIP** and check that the SIM card is correctly inserted or not blocked by the PIN code.
- Also, refer to the "**Troubleshooting**" chapter (see page 45).

PROGRAMMING BY HANDSET

Allows customization of the device according to specific requirements. Programming can be done manually using a multifrequency handset equipped with a keypad.

It is necessary to lift the handset to program.

MAIN PARAMETERS :

- Roaming service configuration
- Warning SMS number
- Administrator number
- Programming password
- Battery charge level control
- Mains power loss control
- Automatic conversion of the selected number
- Receiver gain adjustment
- Transmitter gain adjustment
- Front-end call number
- Gateway identifier number



***For the other parameters, refer to the "Programming Instructions" tables.
(Handset column ☒)***

Note : During programming, there must not be more than 5 seconds between each digit. After 5 seconds without input, a warning tone will sound, and it will be necessary to hang up.

Note : At the end of each programming, if it is correct, a confirmation tone will sound. If it is incorrect, an error tone will sound. In all cases, the selection prompt tone will follow, allowing you to proceed with programming and make a call.

Note : It is possible to perform the programming even without a network. After the confirmation or error tone, the no-network tone will follow. You can continue programming or hang up.

The format on the handset must be as follows :

<Prefix>N*X#

OR :

<Prefix>: ** -> Start of keypad programming

N -> Instruction

X -> Parameter value

Example Instruction 40, **NETWORK SIGNAL LEVEL MEASUREMENT :**

Reading -> ** 40#

Example Instruction 12, **OPERATION MODE :**

Writing -> ** 12*X#

SMS PROGRAMMING

SMS programming can be performed from any mobile handset or other device capable of sending SMS.

If the administrator number has been configured, SMS programming is only allowed from this handset number.

A confirmation notification SMS of the programming is sent from the PGA to the number that sent the programming SMS.



ATTENTION

SMS programming may not work if the required format is not followed.

Each programming SMS must contain the password required to access the programming and the codes for the programming tasks to be performed.

The format of the SMS message must be as follows :

Writing : **<Prefix>*xxx#N*X#**

Reading : **<Prefix>*xxx#NR**

Or :

<Prefix>: AN-PGA

-> Start of the programming string

***XXX#**

-> Password string (default XXX = 0)

N

-> Instruction

X

-> Parameter value

-> Programming code separator character or end-of-string character

R -> Character indicating a read operation

Example Instruction 40, **NETWORK SIGNAL LEVEL MEASUREMENT :**

Reading -> AN-PGA*0#40R

Example Instruction 12, **OPERATION MODE :**

Reading -> AN-PGA*0#12R

Writing -> AN-PGA*0#12*X#

MQTT PROGRAMMING VIA IP

MQTT programming via IP can be performed from the ANEP server or using the ANEP programming web application.

The format of the IP message must be as follows :

Writing : <Prefix> N*X#

Reading : <Prefix> NR

Or :

<Prefix>: conf -> Start of the programming string

N -> Instruction

X -> Parameter value

-> Programming code separator character or end-of-string character

R -> Character indicating a read operation

Example Instruction 40, **NETWORK SIGNAL LEVEL MEASUREMENT :**

Reading -> conf 40R

Example Instruction 12, **OPERATION MODE :**

Reading -> conf 12R

Writing -> conf 12*X#

PROGRAMMING INSTRUCTIONS

Code	Function	Command	Handset	SMS	MQTT IP	Format	Comment
------	----------	---------	---------	-----	---------	--------	---------

The factory-set value is indicated **in bold and blue characters**.

1	IDENTIFICATION GATEWAY TYPE	Reading	☐	☒	☒	<prefix>1R	Answer : AN?PGA*0#1* PGA000000000 PGA02.01 PGA00-B EC200AEUHAR01A24M16_01.200.01.200 862997061224485 ATC:4G VoLTE MCC:208 MNC:20 TAC:7530 Cell:7A12504 RSRP:-8 6 RSRQ:-10 OFH #	page 36
2	FORCING PROVISIONING	Writing	☒	☒	☒	<prefix>2#		
4	RELAY CONTROL	Writing	☒	☒	☒	<prefix>4*X#	X from 0 to 1 0: open	
		Reading	☐	☒	☒	<prefix>4R	1: closed	
6	BATTERY STATUS READOUT	Reading	☒			<prefix>6#	By Handset : 1 BEEP : low battery voltage 25% 2 BEEP : battery average 50% 3 BEEP : Battery good 75% 4 BEEP : Battery 100% charged	page 37
				☒	☒	<prefix>6R	By SMS : 1 : Battery low 25% 2 : Average battery 50% 3 : Battery good 75% 4 : Battery 100% charged	
7	REMOTE UPDATE	Writing	☐	☒	☐	<prefix>7#		
8	RESTART (REBOOT)	Writing	☒	☒	☒	<prefix>8#		page 38
9	RESET FACTORY SETTINGS	Writing	☒	☒	☒	<prefix>9#		
10	DELAY BEFORE DIALING THE CALL NUMBER	Writing	☒	☒	☒	<prefix>10*X#	X: 2 Delay after which the number will be dialed	
		Reading	☐	☒	☒	<prefix>10R		
12	HOW TO USE	Writing	☒	☒	☒	<prefix>12*X#	X from 1 à 2 1 : Tone played by network	
		Reading	☐	☒	☒	<prefix>12R	2 : Tone played by gateway	
15	ITINERANCE (ROAMING) (1)	Writing	☒	☒	☒	<prefix>15*X*MCCMNC#	MCC : MCC Code MNC : MNC Code X from 0 to 2 0 : Off 1 : On 2 : Auto fallback	
		Reading	☐	☒	☒	<prefix>15R		
16	PERIODIC NETWORK DISCONNECTION	Writing	☒	☒	☒	<prefix>16*X#	X from 0 to 1 0 : Disabled	
		Reading	☐	☒	☒	<prefix>16R	1 : Activé	
17	PERIODICITY OF PERIODIC NETWORK DISCONNECTION IN DAYS	Writing	☒	☒	☒	<prefix>17*X#	X from 0 to 100 1: 1 day	
		Reading	☐	☒	☒	<prefix>17R		
20	TRANSMISSION GAIN SETTING (2)	Writing	☒	☒	☒	<prefix>20*X#	The gain range is from 0 to 36 (expressed in dB) 0 : Very high gain 15 : Medium gain 36 : Very low gain	page 29
		Reading	☐	☒	☒	<prefix>20R		
21	RECEPTION GAIN SETTING (2)	Writing	☒	☒	☒	<prefix>21*X#	The gain range is from 0 to 36 (expressed in dB) 0 : Very high gain 15 : Medium gain 36 : Very low gain	
		Reading	☐	☒	☒	<prefix>21R		

PROGRAMMING INSTRUCTIONS

Code	Function	Command	Handset	SMS	MQTT IP	Format	Comment
------	----------	---------	---------	-----	---------	--------	---------

The factory-set value is indicated **in bold and blue characters**.

28	ADMIN HANDSET NUMBER (2)	Writing	☐	☒	☒	<prefix>28*X...X*X...X#	Warning : You must include the country code before the phone number. Ex : 33145101304
		Deletion	☒	☒	☒	<prefix>28#	
		Reading	☐	☒	☒	<prefix>28R	
29	PASSWORD PROGRAMMING	Writing	☒	☒	☒	<prefix>29*X*Y*Y#	Warning : 3 digits max Default : 0 X : Old password Y : New password
35	SOURCE NUMBER AUTO-CONVERSION	Writing	☒	☒	☒	<prefix>35*Y*Z*Z#	The indexes range from 1 to 10, allowing a total of 10 phone numbers. Numbers dialed by the device that are not recognized are automatically added to the table. This makes it possible to later query the table and identify new numbers. Y: Index value ranging from 1 to 10 Z: Phone number
		Deletion	☒	☒	☒	<prefix>35*Y#	
		Complete erasure	☒	☒	☒	<prefix>35#	
		Reading	☐	☒	☒	<prefix>35YR	
36	DESTINATION NUMBER AUTO-CONVERSION	Writing	☒	☒	☒	<prefix>36*Y*Z*Z#	Y: Index value from 1 to 10 Z: Phone number (destination)
		Deletion	☒	☒	☒	<prefix>36*Y#	
		Complete erasure	☒	☒	☒	<prefix>36#	
		Reading	☐	☒	☒	<prefix>36YR	
40	NETWORK SIGNAL LEVEL MEASUREMENT	Reading	☒			<prefix>40#	Signal Measurement: 1 : Low 2 : Medium 3 : Good 4 : Very Good
				☒	☒	<prefix>40R	
43	NETWORK MODE CONFIGURATION	Writing	☒	☒	☒	<prefix>43*X#	Network Type Setting: 0 : Automatic 1 : 2G 2 : 3G 3 : 4G
		Reading	☐	☒	☒	<prefix>43R	
50	HANDSET NUMBER FOR NOTIFICATION	Writing	☒	☒	☒	<prefix>50*X...X*X...X#	
		Deletion	☒	☒	☒	<prefix>50#	
		Reading	☐	☒	☒	<prefix>50R	
52	HANDSET NUMBER FOR ANEP PROTOCOL	Writing	☒	☒	☒	<prefix>52*X...X*X...X#	
		Deletion	☒	☒	☒	<prefix>52#	
		Reading	☐	☒	☒	<prefix>52R	
54	ANEP PROTOCOL IDENTIFIER	Writing	☒	☒	☒	<prefix>54*X...X*X...X#	The identifier corresponds to the transmitter number of the ANEP BOX. Format: 8-digit numeric Example: 53104578
		Deletion	☒	☒	☒	<prefix>54#	
		Reading	☐	☒	☒	<prefix>54R	

page 30

page 32

PROGRAMMING INSTRUCTIONS

Code	Function	Command	Handset	SMS	MQTT IP	Format	Comment
------	----------	---------	---------	-----	---------	--------	---------

The factory-set value is indicated **in bold and blue characters**.

58	GSM VOICE DOMAIN PREFERENCE	Writing	☒	☒	☒	<prefix>58*X#	X from 0 to 1 0 : Voice 1 : Data
		Reading	☐	☒	☒	<prefix>58R	
60	BATTERY CHECK	Writing	☒	☒	☒	<prefix>60*X#	X from 0 to 1 0: Enabled 1: Disabled
		Reading	☐	☒	☒	<prefix>60R	
62	BATTERY THRESHOLD	Writing	☒	☒	☒	<prefix>62*X#	X from 0 to 6 0 : 4H 1 : 3H30 2 : 3H 3 : 2H30 4 : 2H 5 : 1H30 6 : 1H
		Reading	☐	☒	☒	<prefix>62R	
65	IN-BAND / OUT-OF-BAND MODE	Writing	☒	☒	☒	<prefix>65*X#	X from 0 to 1 0 : IN-BAND 1 : OUT-OF-BAND
		Reading	☒	☒	☒	<prefix>65R	
71	TELEPHONE LINE VOLTAGE	Writing	☒	☒	☒	<prefix>71*X#	X from 0 to 1 0 : 36 Vdc 1 : 52 Vdc
		Reading	☐	☒	☒	<prefix>71R	
72	SIM CARD NUMBER	Writing	☒	☒	☒	<prefix>72*X#	
		Deletion	☒	☒	☒	<prefix>72#	
		Reading	☐	☒	☒	<prefix>72R	
82	PERIODIC TEST CALL NUMBER	Writing	☒	☒	☒	<prefix>82*X...X*X...X#	
		Deletion	☒	☒	☒	<prefix>82#	
		Reading	☐	☒	☒	<prefix>82R	
83	PERIODIC TEST MODE	Writing	☒	☒	☒	<prefix>83*X#	X from 0 to 1 0 : Voice call 1 : SMS
		Reading	☐	☒	☒	<prefix>83R	
84	PERIODIC TEST INTERVAL	Writing	☒	☒	☒	<prefix>84*XX#	XX from 0 to 99 1 -> 10 days 11 -> 99 hours 1 (1 day)
		Reading	☐	☒	☒	<prefix>84R	
85	PERIODIC TEST TIME	Writing	☒	☒	☒	<prefix>85*HHMM#	HH: Hours, MM: Minutes The test will occur 15 minutes after power-up
		Reading	☐	☒	☒	<prefix>85R	
87	PERIODIC TEST	Writing	☒	☒	☒	<prefix>87*X#	X from 0 to 2 0: Disabled 1 : Enabled 2 : Forced
		Reading	☐	☒	☒	<prefix>87R	
90	GATEWAY TYPE IDENTIFICATION	Reading	☐	☒	☒	<prefix>90R	Refer to instruction 1!
91	MAIN POWER CHECK	Writing	☒	☒	☒	<prefix>91*MMRR#	MM : Delay (in minutes) before detection of main power failure (range: 01 to 99) RR : Delay (in minutes) before detection of main power recovery (range: 01 to 99) Default value: 0103
		Reading	☐	☒	☒	<prefix>91R	

page 33

p.36


page 34

PROGRAMMING INSTRUCTIONS


Code	Function	Command	Handset	SMS	MQTT IP	Format	Comment
<i>The factory-set value is indicated in bold and blue characters.</i>							
92	PIN CODE SETUP	Writing	☒	☒	☒	<prefix>92*X...X*X....X#	
		Reading	☐	☒	☒	<prefix>92R	
93	PIN CODE ENABLE / DISABLE	Writing	☒	☒	☒	<prefix>93*X*YYYY#	X from 0 à 1 0 : Disabled 1: Enabled
		Reading	☐	☒	☒	<prefix>93R	
94	CHANGE PIN CODE (7)	Writing	☒	☒	☒	<prefix>94*XXX*YYY*ZZZ#	XXX : Current PIN code YYY : New PIN code ZZZ : Confirm new PIN code
B	PROVISIONING ADDRESS	Writing	☐	☒	☒	<prefix>B*X#	ANEP Provisioning X : http(s):// (Provisioning server address)
		Reading	☐	☒	☒	<prefix>BR	
T	GATEWAY TIME AND DATE RETRIEVAL	Reading	☐	☒	☒	<prefix>TR	

VoLTE / IP VoLTE

By default (factory settings), the gateway operates in 4G VoLTE mode with 2G/3G fallback



By enabling IP VoLTE mode, the PGA gateway converts DTMF signals for transmission over the data channel.



INSTRUCTIONS DE PROGRAMMATION IP VoLTE


Code	Function	Command	Handset	SMS	MQTT IP	Format	Comment
The factory-set value is indicated in bold and blue characters .							
CFG	SELECTED APN	Writing	☐	☒	☒	<prefix>CFG*<apn>*<user>*<pwd>#	C is used for apn name F is used for user G is used for pwd
		Reading	☐	☒	☒	<prefix>CFGR	ORANGE --> AN-PGA*0#Corange#F#G# ORANGE --> AN-PGA*0#Corange.m2m.spec#F#G# BOUYGUES --> AN-PGA*0#Cmmsbouygtel.com#F#G# BOUYGUES --> AN-PGA*0#Cobjcobytel#F#G# BOUYGUES --> AN-PGA*0#CobjcoPprive#F#G# BOUYGUES --> AN-PGA*0#Ca2bouygtel.com# SFR --> AN-PGA*0#Csl2sfr#F#G# SFR --> AN-PGA*0#Cm2minternet#F#G#
57	TRANSLATION MODE	Writing	☒	☒	☒	<prefix>57*X#	X from 0 to 2 (Note: option 2 is not functional) 0 : Transparent
		Reading	☐	☒	☒	<prefix>57R	1 : P100 Emulation and data sent to MQTT broker server 2 : DTMF translation handled by the server (not functional)
D	SERVER ADDRESS	Writing	☐	☒	☒	<prefix>D*<server>#	ANEP IP VoLTE Server
		Reading	☐	☒	☒	<prefix>DR	Server : mqtt://<server>
E	SERVER PORT	Writing	☐	☒	☒	<prefix>E*<port>#	Communication Port: 1883
		Reading	☐	☒	☒	<prefix>ER	
P	PASSWORD	Writing	☐	☒	☒	<prefix>P*<pwd>#	pwd :
		Reading	☐	☒	☒	<prefix>PR	
U	USERNAME	Writing	☐	☒	☒	<prefix>U*<username>#	username :
		Reading	☐	☒	☒	<prefix>UR	

VoIP

When connecting to the provisioning server at first power-up, this function can be activated automatically.

Otherwise, refer to the VoIP command table to activate the feature manually.

Note : The gateway switches to VoLTE fallback mode if the VoIP communication fails.



VoIP: End-to-end private IP over an Internet connection

VoIP PROGRAMMING INSTRUCTIONS

Code	Function	Command	Handset	SMS	MQTT IP	Format	Comment
The factory-set value is indicated <i>in bold and blue characters</i> .							
66	DTMF MODE IN VoIP	Writing	☒	☒	☒	<prefix>66*X#	X from 0 to 1 0: INBAND 1: OUTBAND
		Reading	☐	☒	☒	<prefix>66R	
70	VoIP RECEIVE VOLUME	Writing	☒	☒	☒	<prefix>70*X#	X from 0 to 100 50
		Reading	☐	☒	☒	<prefix>70R	
73	CALL MODE	Writing	☒	☒	☒	<prefix>73*X#	XX = 0, 1, 01 ou 10 0: Modem 1: VoIP 01 = Primary transmission via Modem, fallback to VoIP 10 = Primary transmission via VoIP, fallback to Modem
		Reading	☐	☒	☒	<prefix>73R	
74	CODEC	Writing	☒	☒	☒	<prefix>74*X#	X from 0 to 1 0: G711U 1: G711A
		Reading	☐	☒	☒	<prefix>74R	
75	TRANSPORT LAYER	Writing	☐	☒	☒	<prefix>75*X#	X from 0 to 1 0: UDP 1: TCP
		Reading	☐	☒	☒	<prefix>75R	
76	USERNAME	Writing	☐	☒	☒	<prefix>76*<username>#	username:
		Deletion	☐	☒	☒	<prefix>76#	
		Reading	☐	☒	☒	<prefix>76R	
77	PASSWORD	Writing	☐	☒	☒	<prefix>77*<pwd>#	pwd:
		Deletion	☐	☒	☒	<prefix>77#	
		Reading	☐	☒	☒	<prefix>77R	
78	SERVER	Writing	☐	☒	☒	<prefix>78*<server>#	ANEP VoIP Server
		Deletion	☐	☒	☒	<prefix>78#	
		Reading	☐	☒	☒	<prefix>78R	
79	PORT	Writing	☐	☒	☒	<prefix>79*<port>#	Communication Port : 5060
		Reading	☐	☒	☒	<prefix>79R	
81	SIP SESSION TIMEOUT	Writing	☒	☒	☒	<prefix>81*X#	300
		Reading	☐	☒	☒	<prefix>81R	

WiFi



1. Enable WiFi

****5*1#**

2. Enable WiFi on the mobile device

In the list of available WiFi networks, look for AN-PGA-WiFi.

3. Enter the password to connect to the gateway's WiFi network.

WiFi PROGRAMMING INSTRUCTIONS

Code	Function	Command	Handset	SMS	MQTT IP	Format	Comment
<i>The factory-set value is indicated in bold and blue characters.</i>							
5	ENABLE WIFI TETHERING	Writing	☒	☒	☒	<prefix>5*X#	X from 0 to 1 0: Disabled 1: Enabled
		Reading	☐	☒	☒	<prefix>5R	
A	WIFI SECURITY LEVEL CONFIGURATION	Writing	☐	☒	☒	<prefix>A*X#	X from 0 to 3 0: Open 1: WPA 2: WPA2 3: WPA2_PSK
		Reading	☐	☒	☒	<prefix>AR	
C	WIFI PASSWORD	Writing	☐	☒	☒	<prefix>C*X#	X: elevator
		Reading	☐	☒	☒	<prefix>CR	
S	WIFI SSID CONFIGURATION	Writing	☐	☒	☒	<prefix>S*X#	X: AN-PGA-WIFI
		Reading	☐	☒	☒	<prefix>SR	

(1) ROAMING (ITINERANCE)

MCC : Mobile Country Code

208 : France

212 : Monaco

MNC : Mobile Network Code

01 : Orange

10 : SFR

20 : Bouygues

10: Monaco Telecom

Roaming is enabled by default.

To force the device to connect to a specific operator, you must provide the roaming mode, the MCC (Mobile Country Code), and the MNC (Mobile Network Code). The roaming mode can take two values:

- 0 : In this case, the device will connect only when the specified operator's network is available.
- 2 : In this case, the device will first attempt to connect to the specified operator's network, and if unavailable, will automatically switch to roaming mode.

(2) GAIN SETTINGS

CODE CODE

20	21	See programming tables via HANDSET , SMS , or IP (MQTT)
-----------	-----------	---

These settings allow you to adjust the transmit and receive gain.



WARNING

**The default values are optimized for ANEP and P100 DTMF protocols.
Modify them only if absolutely necessary.**

Transmission

0 (**high gain**) to 36 (**low gain**)

Default: 15

Reception

0 (**high gain**) to 36 (**low gain**)

Default: 15

(3) AUTOMATIC CONVERTER OF DIALED HANDSET NUMBER (ROUTING AND MAPPING)

CODE	CODE	
35	36	See programming tables via HANDSET , SMS , or IP (MQTT)

If the function is enabled, the gateway will redirect the call to a predefined number instead of calling the handset number dialed from the connected device (e.g., telealarm **BOX TA** or another telephone device).

It is possible to predefine up to 10 handset numbers to call. Each of them can be linked through programming and/or activation of the function. Each handset number can be associated, via programming, with a dialed number.

When the dialed number is not associated with any predefined handset number, the call will be routed to that same number. Additionally, it will be stored in the first available slot in the preselection table, with the same number set as both "selected" and "predefined". This allows, when sending command 35 (read selected number slots) via SMS or IP, to identify the numbers dialed by the telealarm device, and thus define the 'predefined' number using command 36.

Note : To activate the "Automatic Converter" service, preselect a handset number.

To deactivate this service, all preselected handset numbers must be deleted.

****EXAMPLE : Preselection Table***

Slot	Selected Handset Number (code 35)	Predefined Handset Number (code 36)
1	0123456789*	0601020304*
2	0123456790*	0601020305*
---	---	---
---	---	---
9	0123456793*	0601020309*
10	0123456794*	0601020310*

By selecting handset number 0123456789, the gateway will place a call to 0601020304.

By selecting handset number 0123456790, the gateway will place a call to 0601020305, and so on.

When a number that is not listed in the "Selected Handset Number" column is dialed, the gateway will call that same handset number and automatically add it to the first available slot in the preselection table, using the same number as both "Selected Handset Number" and "Predefined Handset Number"

Automatic Handset Number Mapping:

- Enter the number to be called into a table slot using programming code 36.
- Enter the dialed number to be associated into the same table slot using programming code 35.

An SMS containing the dialed number and the preselected number is sent to the administrator's number (if configured) whenever a new association is created..

An SMS is also sent each time a selection different from the 10 predefined entries is made.

(4) MESURE DE NIVEAU DU SIGNAL

CODE

40

See programming tables via [HANDSET](#), [SMS](#), or [IP \(MQTT\)](#)

This procedure allows you to check the signal level of 2G (GSM), 3G (UMTS), or 4G (LTE) via the handset, by SMS, or over IP (MQTT).

Via handset :

- Pick up the handset and dial : ***C40#**
- Wait for the signal level to be announced.

The gateway will emit a number of short tones corresponding to the signal strength :

Tones	Quality
No tone	No signal / No network
1 tone	Low (<i>non functional</i>)
2 tones	Medium (<i>unstable or random</i>)
3 tones	Good (<i>recommended level</i>)
4 tones	High

The signal may vary; we recommend repeating code ****40#** 2 or 3 times with a few seconds between attempts to obtain a reliable reading.

Note : If the signal is low or medium, we recommend placing the gateway in a different location with better signal reception.

Note : If you receive the "No signal", tone, this means that the gateway has not been properly registered with the network operator.
We recommend trying again after a few moments.

(5) BATTERY ALERT (BATTERY CHARGE LEVEL MONITORING)

CODE CODE

60	62	See programming tables via HANDSET , SMS , or IP (MQTT)
----	----	---

If low battery monitoring is enabled, the **PGA VoIP** constantly checks the battery charge level.

When the charge level drops below the threshold required to guarantee 3 hours of standby autonomy, a warning message is sent to a pre-registered number.

This information is transmitted either by SMS (by default) or to a **monitoring center (DTMF)**.

See «Signaling of external power failure or battery charge level via a **monitoring center (DTMF)**.

Transmission via SMS (default) :

The device sends an SMS when the first configured remaining autonomy threshold is reached. An SMS is then sent at each lower threshold.

For example, if the threshold is set to 3h, the first SMS will be sent when the remaining autonomy drops below 3h.

If the battery is not recharged, the device will send an SMS at 2h30, then 2h, then 1h30, then 1h.

The internal backup batteries ensure 3 hours of standby operation and 1 hour of talk time.

(6) EXTERNAL POWER FAILURE CONTROL

CODE

91

See programming tables via [HANDSET](#), [SMS](#), or [IP \(MQTT\)](#)

If the external power failure control is activated, the gateway continuously checks the external power supply (230Vac or 12Vdc)

If the power failure lasts longer than the predefined time interval, a notification SMS is sent with the following text message :

«Power Failure Detected»

If the external power is restored within a time interval equal to the predefined threshold, a new SMS is sent with the following text message:

«Power Failure Resolved».

(7) SIM CARD PROTECTION

CODE CODE CODE

92	93	94	See programming tables via HANDSET , SMS , or IP (MQTT)
----	----	----	---

WARNING: The PIN code configured in the gateway must match the one of the SIM card, otherwise the SIM may be blocked. However, to prevent the SIM card from being blocked, the device will stop any further PIN code attempts after the first failure. This allows you to insert the SIM card into a handset and still have 2 remaining attempts to enter the correct PIN code.

At device startup, several scenarios are possible :

- SIM card not locked by a PIN code :
 - The device starts normally.
- SIM card locked by a PIN code :
 - The PIN code entered in the device is correct :
 - The device starts normally.
 - The PIN code entered in the device is incorrect :
 - All 4 LEDs turn on solid: refer to the section “Blocked SIM Card.”
 - No PIN code has been entered :
 - All 4 LEDs blink simultaneously: refer to the section “Locked SIM Card.”

Blocked SIM Card

In this situation, it is necessary to insert the SIM card into a phone in order to verify that the PIN code entered in the device is correct.

It is also possible to disable the PIN code.

Locked SIM Card

In this situation, you must enter the PIN code using command 92 :

(**92***<PIN code>*****<PIN code>***)

- If the entered PIN code is correct, the device unlocks the SIM card and starts normally. The PIN code will then be saved in the device, allowing it to automatically unlock the SIM card during the next startup.
- If the entered PIN code is incorrect, the device switches to “Blocked SIM Card” mode.

Activating the PIN Code for the First Time on an Unprotected SIM

If the SIM card is not protected by a PIN code, it is possible to activate the PIN using command 93 :

(**93*1***<PIN code>***)

- If the entered PIN code is valid, it will be saved in the device, allowing automatic SIM unlocking during the next startup.
- If the entered PIN code is incorrect, the device switches to “Blocked SIM Card” mode.

Changing the PIN Code

The PIN code can only be changed when the SIM card's PIN protection is active.

To change the PIN, use command 94:

(**94***<old PIN>*****<new PIN>*****<new PIN>***)

(8) READING ADVANCED GATEWAY PARAMETERS

CODE

1	See programming tables via SMS and IP (MQTT) only.
---	--


This procedure allows you to check the advanced parameters of the device and the **PGA VoIP** GSM gateway.

Send the following SMS to the **PGA** : **AN-PGA*C#1R**

or :

***C#** is the security code (by default, C = 0)

The **PGA VoIP** will send one or two SMS messages back to the number that made the request, containing the following data:



(9) READING BATTERY STATUS

CODE

6	See programming tables via HANDSET , SMS , or IP (MQTT)
----------	---

This procedure allows you to check the battery status via your handset or by SMS reply.

The gateway emits a number of short tones corresponding to the number of guaranteed standby operating hours:

Handset	Standby Hours
No tone	Battery missing or damaged
1 BEEP	Up to 1h30min
2 BEEPS	Up to 2h30min
3 BEEPS	Up to 3h
4 BEEPS	More than 3h30min

SMS, IP	Battery status
No tone	Battery missing or damaged
Battery Low	25% (1)*
Battery Medium	50% (2)*
Battery Good	75% (3)*
Battery Charged	100% (4)*

*** Instruction 6 p.20**

(10) REBOOT (RESTARTING THE DEVICE)

CODE

8	See programming tables via HANDSET , SMS , or IP (MQTT)
----------	---

It is possible at any time, via handset, SMS, or IP, to restart the **PGA VoIP** without cutting the power:

Handset : ****8#**

SMS : **AN-PGA*0#8#**

Note : Restarting the PGA VoIP does not alter its programming.

(11) FACTORY RESET

It is possible to restore the factory configuration at any time using the following code:

CODE

9	See programming tables via HANDSET , SMS , or IP (MQTT)
----------	---

The command 9 (Factory Reset) restores all parameters to their default settings.

Handset : ****9#**

SMS : **AN-PGA*0#9#**

SERVICES

1 - VoLTE

Incoming Phone Calls

Allows you to answer incoming phone calls.

When a phone call is received, the (white) LED indicates the line status.

It briefly flashes 4 times every 4 seconds, as described in the "Indicators" section (see page 44), and the handset rings.

Pick up the handset to answer the call.

The (white) LED indicates the line status, lights up, and the communication with the recipient is established.

Outgoing Phone Calls (VoLTE)

Allows dialing a number over the 4G VoLTE telephone network (with 3G / 2G fallback).

Pick up the handset — the (white) LED indicating line status will light up, and the dial tone will be heard. Dial the handset number to call.

Note : If you hear a deterrent tone when picking up the handset, check the 4G signal strength and ensure the SIM card is functioning properly.

SERVICES

2 - Provisioning


Provisioning Server



1. Insert a Data/Voice SIM card (Minimum 5 MB)
2. Check the quality of the 4G signal
3. At first power-up, and as soon as the internet connection is operational, the PGA VoIP gateway retrieves its configuration, as defined by the elevator installer and their call center, from the ANEP or Client provisioning server.
 - SIP Protocol
 - Inband / Outband Mode (RFC 2833 or 4733)
 - G711
 - VoIP Call Number
 - VoLTE Call Number (fallback mode)
 - Etc...

3 - Remote Configuration via IP

ANEPprogrammation Web



IP



DTMF



ANEP-BOX



LED STATUS GUIDE

Green LED: Network Signal Strength (Blink every 200 ms)



2G, 3G, 4G (without VoLTE)


LED Status	Signal
Off	No signal
	Low
	Medium
	Good
	High

4G (with VoLTE)

LED Status	Signal
Off	No signal
	Low
	Medium
	Good
	High


Red LED: Connected to the mobile network (Flashing every 100 ms) ●

PGA 02.01

LED Status	Connection
On	Disconnected from network
	Registered


Red LED: Alarm transmission type (Flashing every 500 ms) ●

PGA 03.01

LED Status	Alarm transmission
Off	2G/3G/4G VoLTE
	MQTT
Steady	VoIP





Red LED: Alarm transmission type (Flashing every 500 ms) ●

Coming soon





LED Status	Alarm transmission
Off	2G/3G/4G VoLTE
	MQTT
Steady	VoIP

Blue LED: Power Status


Battery unplugged (100 ms interval)

LED Status	Battery Life
Off	Less than 1 hour
	1h to 1h59 min
	2h to 2h59 min
	3h to 3h29 min
	More than 3h30

Battery connected (Flashing every 200 ms)


LED Status	Battery Charge
On	Battery damaged or disconnected
	Low
	Medium
	High
	Full

White LED: Line Status



LED Status	Line Status
On	Line busy
Off	Line not picked up
	Incoming call

Special Patterns

PIN Code (Flashing every 100 ms)

LED Statuses	Description
 (GREEN LED) (RED LED) (BLUE LED) (WHITE LED)	SIM card locked, 3 attempts remaining
ALL LEDs ON	SIM card locked, less than 3 attempts left (unlock with mobile phone)

Manual Factory Reset (Via Jumper, Flashing every 100 ms)

LED Statuses	Description
 (GREEN LED) (RED LED) (BLUE LED) (WHITE LED)	Factory reset warning
 (GREEN LED) (RED LED) (BLUE LED) (WHITE LED)	Waiting for jumper removal before reboot

TROUBLESHOOTING

This chapter lists the most common issues that may occur.

Before contacting technical support, please perform these simple checks.

Condition	Possible Causes	Solutions
Device does not start	- No external power - Battery not connected - SIM card improperly inserted	- Check power supply - Check battery connection - Check SIM card insertion
No signal (Green LED off)	- Antenna not connected - Poor reception - SIM card not activated	- Check antenna connection - Improve antenna placement - Contact SIM provider
No VoLTE (Green LED flashing)	- SIM card not VoLTE-compatible - Weak 4G signal	- Using a 4G VoLTE SIM card - Improve antenna placement
No VoIP (Red/Orange LED off or flashing)	- SIM card without 4G data (Min. 5MB)	- Using a 4G data SIM card (Min. 5MB)
Unable to make outgoing calls	- Line is busy - SIM card is blocked	- Try again later - Check SIM card status - Contact mobile operator
Incoming calls not received	- Device restarting or in standby - SIM not registered on the network	- Wait for restart to complete - Check signal and SIM registration
SMS not sent/received	- No network - SMS service not enabled on SIM card	- Check network connection - Contact mobile operator
Abnormal LED flashing	- SIM card locked - Incorrect PIN entered - System error	- Enter correct PIN code (command 92) - Test SIM in a mobile phone - Contact ANEP support
Frequent device restarts	- Power instability - Faulty battery - System error	- Check power supply - Replace battery - Contact ANEP support

NOTES

ANEP applies a method of continuous development, therefore, ANEP reserves the right to make changes and improvements to any product described in this document, without notice.

ANEP cannot under any circumstances be held liable for any loss of data, as well as any particular damage or incident, resulting from poor implementation or non-compliant use of the product.

The contents of this document are provided “as is”. No warranty of any form, express or implied, is made as to the accuracy, reliability, or content of the document. ANEP reserves the right to revise this document or withdraw it at any time without notice.

WARRANTY

This product is guaranteed for **3 years** from the date of invoicing of the product, with the exception of batteries and cells which are guaranteed for **6 months**.

However, this guarantee does not apply in the event of:

- Use that does not comply with the instructions in this manual.
- Deterioration from a cause external to the product (act of vandalism, fire, flood, storm, overvoltage...).
- Installation carried out by an unqualified installer not approved by ANEP.
- Modifications or repairs carried out by entities not approved by ANEP.
- Opening of the product by a non-ANEP approved person.



IMPORTANT

Particular care and rigor must be taken in the cabling and connection, in order to obtain the best sound results and optimal reliability of the product.

The equipment must be connected, installed and programmed according to the rules of the trade.

THE AFTER SALES SERVICE IS PROVIDED BY

SAVTEL

4 bis rue de Paris 94470 Boissy-Saint-Léger

+33 1 45 98 34 44



Website : www.anepstore.com